

CHEMICAL FLOODING (Polymer)

The method shown requires a preflush to condition the reservoir, the injection of a polymer solution for mobility control to minimize channeling, and a driving fluid (water) to move the polymer solution and resulting oil bank to production wells.

Mobility ratio is improved and flow through more permeable channels is reduced, resulting in increased volumetric sweep.

(Single 5-Spot Pattern Shown)

